

**\*1 18395\***

Page 1

**\*N900040100\***

**Setup Start \*NS1\***

Stop \*NS2\*

Approvals: Process Plan:                      Date:                      Tooling:                      Date:                       
QC:                      Date:                      SPC (Y/N):                      Date:                     

Run	Start	*NR1*
	Stop	*NR2*

Draw Nbr	Revision Nbr
D350-616	G

**\*100\***

Photocopy bluefile and create labels per PPP D350-616-011  
CHG006

**\*1 1 Q\***

**PULL FROM STOCK:**  
1 X D350-616-011 B120950

1 X D350-616-013 B ~~120153~~ 120162  
FOR S/O117645

1 X D350-616-013 B 11937

# Work Order ID 118395

**\*118395\***

August-07-14 7:41:06 AM

Page 2

Item ID: D350-616-011 Accept **\*N900040100\*** Setup Start **\*NS1\***  
 Revision ID: Stop **\*NS2\***  
 Item Name: Full Emergency Litter  
 Start Date: 8/07/14 Start Qty: 1.00 **\*1\*** Cust Item ID:  
 Required Date: 8/07/14 Req'd Qty: 1.00 **\*1\*** Customer:  
 Reference: disassemble

Approvals: Process Plan: \_\_\_\_\_ Date: \_\_\_\_\_ Tooling: \_\_\_\_\_ Date: \_\_\_\_\_ Run Start **\*NR1\***  
 QC: \_\_\_\_\_ Date: \_\_\_\_\_ SPC (Y/N): \_\_\_\_\_ Date: \_\_\_\_\_ Stop **\*NR2\***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
120	QC4- 100% Inspect kits for completeness	0.00							
<b>*120*</b>									
QC	Memo	0.00							DAS 38 9-89 14-9-2
Quality Control	RE-INSPECT KIT								
130		0.00							
<b>*130*</b>									
Packaging	Memo	0.00							
Packaging	REPACKAGE USING NEW B/N NEW LABELS REQ'D Identify and pack for shipping as per PPP D350-616-011 Location: _____ PPP Rev: _____								AUG 02 2013 DAS 06 9-89
140	QC21- Final Inspection - Work Order Release	0.00							
<b>*140*</b>									
QC	Memo	0.00							
Quality Control									MLJ 14-09-02

W 14-09-02

# Picklist Print

August-07-14 7:41:05 AM

Page 1

Work Order ID: 118395

**\*118395\***

Parent Item: D350-616-011

**\*D350-616-011\***

Parent Item Name: Full Emergency Litter

Start Date: 8/07/14

Required Date: 8/07/14

Start Qty: 1.00

Required Qty: 1.00

**Comments:**

IPP E03.04.04ReformatKJ/RF

IPP Rev:F 08-12-10 rev.E as per dwg DD verified by:ec IPP REV:G

13.05.21 AS PER DWG REV.G DD VERF:JLM

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
---------------------------------	------------------------	---------------	-------------	---------------------	------------------	-----------------	--------------------	----------------	-------------	--------------	---------------	----------------	--------

D350-616-011

Manufactured

No

Each

1.0000

1

**\*D350-616-011\***

Full Emergency Litter

**\*\***

120950

*[Handwritten mark]*

Location

Loc Qty

Loc Code

FG031

1

120105

1

D350-616-013

**DAS** Manufactured

No

Each

0.0000

**\*D350-616-013\***

Deck Plate & Tie Down

**\*\***

120162

*[Handwritten mark]*

D350-616-013

Manufactured

No

Each

0.0000

1

**\*D350-616-013\***

Deck Plate & Tie Down

**\*\***

119371

**DAS**

**96**

**9-89**